


ACCESSORIES

Models STR-H6A

Installation/Operation




EN55103-1 E1-E5; EN55103-2 E1-E4
Typical Performance reflects product at publication time
exclusive of EMC data, if any, supplied with product.
Specifications are subject to change without notice.



Step 1
Slide STICK-ON Modules into
the STR-H6A.

Step 2
Use Cable Ties to Secure Wiring.

Step 3
Connect Shields to Ground Terminal.
(normal for inputs, optional for outputs)



STICK-ON Module Terminal Block