

STR-H711 BOARD HEADER ASSIGNMENTS

EXT1			EXT2				
P0.1	1	0	P0.0	GND	38	39	nRST
P0.3	3	2	P0.2	5V-USB	36	37	3.3V
P0.5	5	4	P0.4	BOOTEN	34	35	STB
P0.7	7	6	P0.6	V1.8BKP	32	33	1.8V
P0.9	9	8	P0.8	P1.14	30	31	P1.15
P0.11	11	10	P0.10	DN	28	29	CLK
P0.13	13	12	P0.12	P1.10	26	27	DP
P0.15	15	14	P0.14	P1.8	24	25	P1.9
P1.1	17	16	P1.0	P1.6	22	23	P1.7
P1.3	19	18	P1.2	P1.4	20	21	P1.5

The pin numbers are printed on the top silkscreen, the above drawings are with TOP view of the board

The distance between the headers is 1"