



NOTE:

SIGNAL AND POWER CONTACTS

COME PRE-LOADED INTO INSULATORS

DESCRIPTION: 681 SERIES CONTACTS