

## **1000A 3-Phase Power & Harmonics Analyzer**



For power measurements and analysis Of single and 3-phase/3-wire or 3-phase/4-wire systems

## **Features:**

- Large backlighting LCD displays up to 35 parameters in one screen (3P4W)
- Clamp-on True RMS power measurements with on-screen Harmonics display (1-99th order)
- · Simultaneous display of Harmonics and Waveform
- · Display of Waveform with Peak Values (1024 samples/period)
- Analysis of Total Harmonic Distortion (THD-F)
- Displays Active Power (kW), Apparent Power (kVA), Reactive Power (kVAR) and Power Factor
- kWH and kVARh energy measurements
- Maximum Demand (MDkW, MW, kVA, MVA) with programmable period
- · Adjustable CT ratio (1 to 600) and VT ratio (1 to 3000)
- · Graphic Phase diagram with 3-Phase system parameters
- 3-phase Voltage or Current Unbalanced Ratio (VUR, VIR) and Unbalanced Factor (d0%, d2%)
- Calculated Unbalanced Current through Neutral Line (In)
- Datalogger records up to 52428 records in single phase,

(17476 records in 3-phase)

- Capture 28 Transient events (including Dip, Swell and Outage) with programmable threshold (%)
- Optically isolated RS-232 interface with software to download Waveforms, **Power Parameters and Harmonics**
- Complete with (3) 1000A current clamps, 4 voltage leads with alligator clips, 8 AA batteries, AC adaptor, software, PC interface cable, and carrying case.

## **Ordering Information:**


382095 ......1000A 3-Phase Power Harmonics Analyzer (110V) 382096 ......1000A 3-Phase Power Harmonics Analyzer (220V) Accessories

- 382000 ......Voltage Test Leads with Alligator Clips (4 leads) 382097 ......100A Current Clamp Probes (Set of 3)
- 382098 ....... 3000A, Flexible Current Probes (Set of 3)
- USB100 ......RS-232 to USB Adaptor



Optional 3000A Flexible Current Clamp Probes 24" (610mm) long for wrapping around busbars (Model 382098)





Optional 100A Current Clamp Probes (Model 382097) with 1.2" (30mm) jaw size

Phase Analysis





DATALOGE	KER SETUP	Press to get databagger categ
HE MED	MC #HO	Clear Memory
0.00	PERMIT	Down Load Power Dat
Per farment	Harried Bushers	Down Load Power Dat
		Down Load Hamsonic
COTTY MM SES	Dist Not Till	and the second states of the
1005-07-08	11.66.75	Down Loed Translerd

Software included to download.

store data and display on a PC

Harmonics Analysis

Software Harmonics

Phase Analysis

		HOUSE	新	10.0.0		
P	Tale-	Horth	Date 22	Hour	nired.e	flecor 10
	Inter	mal I	Men	u		

	TIT	
		 -
	20 Aug. 201	 

Software Harmonics Analysis



## www.extech.com

Complete with (3) 1000A current clamps, 4 voltage leads with alligator clips, 8 AA batteries, AC adaptor, software, PC interface cable, and carrying case