



# Heyco® Original Strain Relief Bushing Air Tool, Air Tool Jaws & Replacement Parts

## Air Tool and Air Tool Jaws Directory

### Ordering Procedure for Air Tools:

- On the tabular chart, locate the panel mounting hole diameter and Original Strain Relief Bushing that you are using.
- The appropriate Air Tool is shown on the same line.
- Jaws may be purchased separately, see the two right most PART NO. columns.
- Bench Mount Kit **Part No. OT02** provides the necessary components to convert a hand Air Tool to a bench mounted unit. The bench Air Tool can be mounted in any convenient position on the assembly area work surface. The unit is foot activated, leaving the operator's hands free. See below.
- For Original Strain Relief **Assembly Pliers**, see pages 4-27 & 4-28.
- For attaching Pliers for Metal Strain Reliefs, see page 4-30.

PANEL HOLE DIAMETER		FOR ORIGINAL STRAIN RELIEF BUSHINGS	AIR TOOL PART NO. inc. Jaws	JAW PART NO. *	
in.	mm.			Upper	Lower
.375	9,5	2L-1, 2M-1, 2P-4, 2P-5	0171	0T47	0T48
.437	11,1	3A-4	0173	0T49	0T50
		3L-1, 3P-4, 3P-5, 3W-1, 13-1	0175	0T51	0T52
		4A-6, 14A-1	0177	0T53	0T54
.500	12,7	4K-1, 4K-4, 4K-6, 4L-1, 4L-4, 4N-4, 4N-5, 4N-6, 4N-7, 4P-4, 5L-1, 5M-3, 5MN-3, 5N-4, 5N-5, 5N-7, 5P-4, 5P-7, 5P3-4, 6W-1, 14-1, 15-1	0179	0T55	0T56
.562	14,3	5K-4, 5KN-4, 5W-1, 16-1	0181	0T59	0T60
.625	15,9	6K-5, 6L-1, 6N-4, 6N-7, 6N2-4, 6N3-4, 6N3-5, 6N3-7, 6N4-4, 6P-4, 6P-5, 6P-7, 6P2-5, 6P3-4, 6P3-5, 6P3-7, 6P4-4, 6P10, 6P30, 10N-2, 10-2, 11-2, 11K-2	0183	0T61	0T62
.750	19,0	7N-2	0185	0T63 <sup>1</sup>	0T64 <sup>2</sup>
		7P-2, 7P-7, 17-2	0187	0T65 <sup>1</sup>	0T66 <sup>2</sup>
.875	22,2	7K-2, 7KR-2, 7L-2, 7W-2, 8L-1, 8P-2, 24-1, 31-2, 34-2	0189	0T67 <sup>1</sup>	0T68 <sup>2</sup>
		8N-2	0193	0T71 <sup>1</sup>	0T72 <sup>2</sup>
.375x.625	9,5x15,9	300-1, 302-1	0191	0T69	0T70
.560 x .730	14,2 x 18,5	20-1, 20L-1, 30-1, 30-1A, 30-1B	0195	0T73	0T74
.750 x .875	19,0 x 22,2	23-1, 33-1	0197	0T75	0T76 <sup>2</sup>

<sup>1</sup> Secondary (upper) Jaw style. When ordering additional spacer may be required (P/N OT36[2]).

<sup>2</sup> Secondary (lower) Jaw style. When ordering additional spacer may be required (P/N OT77[1]).

\*Jaw part number if purchased separately. See drawing below.

## Air Tool Replacement Parts



Part No. OT02 Bench Mount Kit shown installed with Heyco Air Tool

