

The FB120A and FB230A are used to monitor the operation of one two-lamp incandescent beacon and one beacon flasher (or auxiliary module). The flasher and lamps are monitored by sensing the flow of current in the circuit. If the lamp(s) or the flasher fail to operate properly, a solid-state output and an isolated SPDT relay energize. When connected to a site monitoring system, this unit provides the remote beacon monitoring protection required by the FAA/FCC. On a multiple beacon structure, one unit is required for each two-lamp incandescent beacon (one unit per beacon for LED beacons).

For more information see:

Appendix B, page 167, Figure 32 for dimensional drawing. Appendix C, page 171, Figure 31 for connection diagram.

Operation

If one lamp in an incandescent beacon fails, the relay and solid-state lamp failure outputs energize after 10s. If the flasher fails in the ON or OFF condition, the relay and the solid-state flasher failure output energizes after 6s. If both failures occur, all three outputs energize after their trip delays.

Note: If both incandescent lamps fail, all three outputs will energize. The relay and solid-state flasher failure output energizes after 6s, and the solid-state lamp failure output energizes after 10s.

Features:

- Senses failed flashing incandescent beacon lamps & beacon flashers
- Toroidal current sensing
- One isolated, 5A, SPDT alarm output
- Two 1A, solid-state line voltage alarm outputs
- Trip delays prevent nuisance alarms

Available Models:

FB120A FB230A

Order Table:

Input 120VAC 230VAC Lamp Type Incandescent Beacon Incandescent Beacon Part Number FB120A FB230A


Specifications

Input Voltage FB120A FB230A	
AC Line Frequency	
Lamp Socket Voltage	
Alarm Outputs	
Type	3 total - 1 relay, 2 solid state; One isolated SPDT relay rated 5A resistive Two solid-state line voltage outputs rated 0.5A steady, 5A inrush
Lamp Failure Detection	
FB120A	For two 620W or 700W lamps

Lamp Failure	. Fixed at 10s; -0/+40%
	C1
Lamp Failure (Red)	
Flasher Failure (Red)	. Glows when the flasher fails
Protection	
Circuitry	. Encapsulated
Mounting	. Surface mount with two #6 (M3.5 x 0.6) screws
Dimensions	. 3.5 x 2.5 x 1.75 in. (88.9 x 63.5 x 44.5 mm)
Termination	.7 position barrier block for 20 AWG (0.5 mm ²)
	to 14 AWG (2.5 mm²) wire
Environmental	
Operating / Storage Temperature40° to 60°C / -40° to 85°C	
Weight	. ≅ 7 oz (198 g)


Appendix B - Dimensional Drawings

FIGURE 24




LPM

FIGURE 27











FIGURE 26



LLC1




FIGURE 29




FIGURE 30

LLC2




FIGURE 32






FIGURE 33




inches (millimeters)

FIGURE 31



ARP

Appendix C - Connection Diagrams



F = Flasher (FS155-30T, FS155-30RF, FS165-30T, FS165-30RF)


AX = Auxiliary Unit

B = Beacon

DL = Dummy Load for Constant Line Loading Rd = $3.3 \text{ K}\Omega$ @ 5W for 120VAC

8.5 KΩ @ 5W for 230VAC

FIGURE 32 - SCR490D



V = Voltage


OL = Obstruction Lamps T = Toroid

SS = Selector Switch

AXL = Auxiliary Load/Alarm

Relay contacts are isolated.

FIGURE 31 - FB Series



B = Beacon F = Flasher

BRC = Flasher Bypass Relay Contacts

T = Toroid

AR = FB Alarm Relay

BR = Bypass Relay Coil

FL = Flasher Failure LED


LL = Lamp Failure LED AXL = Lamp Alarm Relay Coil

NOTE: Flasher module may be located on either the


line or load side of the toroidal sensor.

FIGURE 33 - SCR Series

Beacon Connection Diagram



Obstruction Lamp Connection Diagram



B = Beacon Lamps

SS = Selector Switch

T = Toroid

F = Flasher

AXL = Auxiliary Load/Alarm

OL = Obstruction Lamps

Relay contacts are isolated.