

Provides protection for motors and other sensitive loads. Continuously measures the voltage of each of the three phases using a microcomputer circuit design that senses under and overvoltage, voltage unbalance, phase loss, and phase reversal. Protection is provided even when regenerated voltages are present. Includes a trip delay to prevent nuisance tripping and a restart delay to prevent short cycling after a momentary power outage.

For more information see:

Appendix B, page 167, Figure 30 for dimensional drawing. Appendix C, page 168, Figure 14 for connection diagram.

#### **Features:**

- Protects against phase loss & reversal; over, under & unbalanced voltages; short cycling
- Fixed trip points & delays
- Fixed voltages from 208 to 480VAC
- Isolated, 10A, SPDT ouput contacts
- Bi-color LED indicator shows: output status, faults, time delays & phase reversal
- ASME A17.1 rule 210.6
- NEMA MG1 14:30, 14:35
- IEEE C62.41-1991 Level B

Approvals: (E RI)

#### **Auxiliary Products:**

· Female quick connect: P/N: P1015-13 (AWG 10/12) P/N: P1015-64 (AWG 14/16) P/N: P1015-14 (AWG 18/22)

- 3-phase fuse block/disconnect: P/N: FH3P
- **2** Amp fuse: P/N: P0600-11 Voltage reduction module:
- P/N: VRM6048

#### **Available Models:**

TVM208A100.5S3S TVM460A510S5S TVM230A101S1S TVM460A75S2M TVM400A101S1S TVM480A100.5S3S TVM460A101S1S TVM480A50.5S2S TVM460A41S5M

If desired part number is not listed, please call us to see if it is technically possible to build.

#### Operation

Upon application of line voltage, the restart delay begins. The output relay is de-energized during restart delay. Under normal conditions, the output energizes after restart delay. Undervoltage, overvoltage, and voltage unbalance must be sensed for continuous trip delay period before the output is de-energized. The output will not de-energize if a fault is corrected during the trip delay. The restart delay begins as soon as the output relay deenergizes. If the restart delay is completed when the fault is corrected, the output relay will energize immediately. The output relay will not energize if a fault or phase reversal is sensed as 3-phase input voltage is applied. Reset: Reset is automatic upon correction of a fault.

#### LED Operation

The LED flashes green during the restart delay, then glows green when the output energizes. It flashes red during the trip delay then glows red when the output de-energizes. It flashes red/green if phase reversal is sensed.

#### Order Table:

**TVM** Line Voltage **-208A** - 208VAC -220A - 220VAC -230A - 230VAC -240A - 240VAC -380A - 380VAC **400A** - 400VAC **-415A** - 415VAC -440A - 440VAC

**-460A** - 460VAC

-480A - 480VAC

Voltage Unbalance -Fixed - Specify 4-10% in 1% increments

Trip Delay\* **-Fixed** - Specify from **0.2-1**s in 0.1s increments Fixed - Specify from 1-100s in 1s increments

\*Must indicate (S) for secs. or (M) for mins

## Restart Delay\*

Output

-Fixed - Specify from 0.5-1s in 0.1s increments

-Fixed - Specify from 1-100s in 1s increments

Fixed - Specify from 1-999min in 1min increments


#### **Specifications**

Line Voltage			
Type	3-phase delta or wye with no connection to neutral		
Input Voltage	208 to 480VAC		
AC Line Frequency	50 - 100 Hz		
Phase Sequence	ABC		
Power Consumption	Approx. 2W for 240V units		
1	Approx. 3W for 480V units		
Overvoltage, Undervoltage, & Voltage Unbalance			
	Voltage detection with delay trip & automatic res		
Undervoltage Trip Point	88 - 92% of the selected line voltage		
Reset Voltage	≅ +3% of trip voltage		
Overvoltage Trip Point	109 - 113% of the selected line voltage		
Reset Voltage	≅ -3% of trip voltage		
Trip Variation vs Temperature			
Voltage Unbalance	Factory fixed from 4 - 10%		
Reset On Balance	≅ -0.7% unbalance		
Trip Delay Range	Fixed from 0.2 - 100s ±15% or ±0.1s,		
	whichever is greater		
Restart Delay Range	Fixed from 0.5s - 999m ±15% or ±0.2s,		
	whichever is greater		
Phase Reversal & Phase Loss Response	≤ 200ms; automatic reset		
Phase Loss			

	Output					
	Type			Isolated SPDT relay contacts		
	Rating 2	208 to 2	240VAC (55°C)	10A resistive @ 125VAC, 5A @ 250VAC, 1/4 hp @ 125VAC		
	3	380 to 4	480VAC	10A resistive @ 240VAC, 1/4 hp @ 125VAC, 1/3 hp @ 250VAC, max. voltage 277VAC		
	Life			Mechanical - 1 x 106; Electrical - 1 x 105		
	Protection					
set	Surge			IEEE C62.41-1991 Level B		
		own	208 to 240VAC	≥ 1500V RMS input to output terminals ≥ 2500V RMS input to output terminals		
	Mechanical			1 1		
	Mounting			Surface mount with one #8 (M5 x 0.8) screw		
				2 x 2 x 1.25 in. (50.8 x 50.8 x 31.8 mm)		
	Termination			0.25 in. (6.35 mm) male quick connect terminals		
	Environmental					
	Operating / Storage Temperature			40° to 55°C / -40° to 85°C		
				95% relative, non-condensing		
	Weight			≅ 2.8 oz (79 g)		


# Appendix B - Dimensional Drawings

#### FIGURE 24





LPM

#### FIGURE 27












# FIGURE 26



LLC1



#### FIGURE 29



#### FIGURE 30

LLC2






FIGURE 32




## FIGURE 33



inches (millimeters)


### FIGURE 31



ARP


# Appendix C - Connection Diagrams

#### FIGURE 1 - FSU1000 Series



S1 = Optional low current switch V = Voltage L = Load

#### FIGURE 2 - FS100 Series



B = Black Wire

FIGURE 3 - FS100 Series




FIGURE 4 - FS200 Series




FIGURE 5 - FS300 Series





FIGURE 6 - FS400 Series



R = Red Wire B = Black Wire W= White Wire

FIGURE 7 - AF Series




FIGURE 8 - FS500 Series






FIGURE 11 - DLMU Series

#### FIGURE 9 - SC3/SC4 Series



for SC3, terminal 6 & load L4 are eliminated.




NO = Normally Open

NC = Normally Closed RS = Optional Remote Reset Switch Relay contacts are isolated.

be installed externally in series with each input. (3)

FIGURE 10 - WVM Series



F = Fuses


CAÚTION:

2 amp max fast acting fuses must

 $\Theta$ 


L1, L2, L3 = Line Voltage Input NO = Normally Open Contact NC = Normally Closed Contact C = Common, Transfer Contact CAUTION: 2 amp max. fast acting fuses are recommended to protect the equipment's wiring. They are not required to protect the DLMU. ! = Select alarm contact connection as N.O. or N.C. when ordering; N.O. Shown.

#### FIGURE 12 - HLMU Series



NC = Normally Closed Contact C = Common, Transfer Contact CAUTION: 2 amp max. fast acting fuses are recommended to protect the equipment's wiring. They are not required to protect the HLMU.


# FIGURE 13 -



F = Fuses  $\emptyset$ A = Phase A = L1  $\emptyset$ B = Phase B = L2  $\emptyset$ C = Phase C = L3 NO = Normally Open

NC = Normally Closed 2A fast acting fuses recommended for safety (not required)

Relay contacts are isolated.



L2 = Phase B

L3 = Phase C

NO = Normally Open

NC = Normally Closed C = Common, Transfer Contact

Relay contacts are isolated. F = 2A Fast acting fuses are recommended,

but not required