
Capacitive sensor BC10-S30-Y1X






Type code	BC10-S30-Y1X		
ldent no.	20100		
Rated operating distance Sn	10 mm		
Rated operating distance Sn	15 mm, non-flush mounting		
Assured sensing range	≤ (0.72 x Sn) mm		
Hysteresis	120 %		
Temperaturdrift	type ≤ ± 20 %		
Repeatability	≤ 2 % of full scale		
Ambient temperature	-25+70 °C		
Voltage	Nom. 8.2 VDC		
Non-actuated current consumption	≤ 1.2 mA		
Actuated current consumption	≥ 2.1 mA		
Switching frequency	ncy 0.1 kHz		
Output function	2-wire, NAMUR		
Approval acc. to	KEMA 02 ATEX 1090X		
ternal capacitance (C _i) / inductance (L _i) 150 nF / 150 µH			
Device designation	Ex II 2 G Ex ia IIC T6/II 1 D Ex ia IIIC IP67 T115 °		
	(max. $U_i = 20 \text{ V}, I_i = 20 \text{ mA}, P_i = 200 \text{ mW}$)		
Design	threaded barrel, M30 x 1.5		
Dimensions	62.5 mm		
Housing material	Plastic, PA		
Material active face	Plastic, PA, yellow		
Admissible pressure on front cap ≤ 5 bar			
x. tightening torque housing nut 5 Nm			
Connection	cable		
Cable quality	Ø 5.2, LifYY, PVC, 2 m		
Cable cross section	2 x 0.34 mm ²		
Vibration resistance	55 Hz (1 mm)		
Shock resistance	30 g (11 ms)		
Chican recipianics			
Protection class	IP67		

• yellow

- ATEX category II 2 G, Ex zone 1
- ATEX category II 1 D, Ex zone 20
- SIL2 as per IEC 61508
- Threaded barrel, M30 x 1.5
- Plastic, PA12-GF30
- Fine adjustment via potentiometer
- DC 2-wire, nom. 8.2 VDC
- Output acc. to DIN EN 60947-5-6 (NA-MUR)
- Cable connection

Wiring diagram



Functional principle

Capacitive proximity switches are designed for non-contact and wear-free detection of electrically conductive as well as non-conductive metal objects.


Switching state

TURCK


Capacitive sensor BC10-S30-Y1X



Mounting instructions / Description	minimum distances	
Distance D	60 mm	
Distance W	30 mm	
Distance S	45 mm	
Distance G	60 mm	
Diameter of the active area B	Ø 30 mm	



The given minimum distances have been checked in compliance with the standard switching distance. Should the sensitivity of the sensors be changed via potentiometer, the data sheet specifications no longer apply.



Capacitive sensor BC10-S30-Y1X



Accessories

Type code	Ident no.	Description	Dimension drawing
MAP-M30	6950013	Mounting adapter; material: Polypropylene; sensor replacement with filled container possible (adapter remains in container during sensor replacement)	M30 x 1,5 0 31 47
BST-30B	6947216	Fixing clamp for threaded barrel devices, with dead-stop; material: PA6	M5 54 42 36 36 30 30
IM1-22EX-R	7541231	Isolating switching amplifier, dual-channel; 2 relay outputs NO; input NAMUR signal; selectable ON/OFF mode for wire-break and short-circuit monitoring; adjustable signal flow (NO/ NC mode); removable terminal blocks; 18 mm width; universal voltage supply unit	104

Capacitive sensor BC10-S30-Y1X



Operating manual

Intended use

This device fulfills the directive 94/9/EC and is suited for use in explosion hazardous areas according to EN60079-0:2012, -11:2012, -26:2007. Further it is suited for use in safety-related systems, including SIL2 as per IEC 61508.

In order to ensure correct operation to the intended purpose it is required to observe the national regulations and directives.

For use in explosion hazardous areas conform to classification

II 2 G and II 1 D (Group II, Category 2 G, electrical equipment for gaseous atmospheres and category 1 D, electrical equipment for dust atmospheres).

Marking (see device or technical data sheet)

Ex II 2 G and Ex ia IIC T6 acc. to EN60079-0 and Ex II 1 D Ex ia IIIC IP67 T115 °C acc. to EN60079-0

Local admissible ambient temperature

-25...+70 °C

Installation / Commissioning

These devices may only be installed, connected and operated by trained and qualified staff. Qualified staff must have knowledge of protection classes, directives and regulations concerning electrical equipment designed for use in explosion hazardous areas.

Please verify that the classification and the marking on the device comply with the actual application conditions.

This device is only suited for connection to approved Exi circuits compliant to EN60079-0 and -11. Please observe the maximum admissible electrical values.

After connection to other circuits the sensor may no longer be used in Exi installations. When interconnected to (associated) electrical equipment, it is required to perform the "Proof of intrinsic safety" (EN60079-14).

When employed in safety systems to IEC 51408 it is required to assess the failure probability (PFD) of the complete circuitry.

Installation and mounting instructions

Avoid static charging of cables and plastic devices. Please only clean the device with a damp cloth. Do not install the device in a dust flow and avoid build-up of dust deposits on the device.

If the devices and the cable could be subject to mechanical damage, they must be protected accordingly. They must also be shielded against strong electro-magnetic fields.

The pin configuration and the electrical specifications can be taken from the device marking or the technical data sheet.

service / maintenance

Repairs are not possible. The approval expires if the device is repaired or modified by a person other than the manufacturer. The most important data from the approval are listed.