#### **RR Series Power Relays**

**Part Number Selection** 

RR2P-U □

RR2P-UL

RR2P-UC □

RR2P-ULC

RR3PA-U 🗌

RR3PA-UL

RR3PA-UC □

RR3PA-ULC

\_

**Pin Terminal** 

Part Number

Blade Terminal\*

RR1BA-U 🗌

RR1BA-UL

RR1BA-UC □

RR1BA-ULC

RR1BA-US □

RR2BA-U □

RR2BA-UL

RR2BA-UC □

RR2BA-ULC □

RR2BA-US □

RR3B-U 🗌

RR3B-UL 🗌

RR3B-UC □

RR3B-ULC

RR3B-US

T (1 (2)

#### **Key features:**

Contact

SPDT

DPDT

3PDT

- SPDT through 3PDT, 10A contacts
- Midget power type relays
- Available in pin and blade terminal styles.
- Options include an indicator, check button for test operations and side flange.
- DIN rail, surface and panel mount sockets are available for a wide a variety of mounting applications.

Model





Standard

Standard

Standard

With Indicator

With Check Button

Side Flange Model

With Indicator

With Indicator With Check Button

Side Flange Model

With Check Button

Side Flange Model

With Indicator and Check Button

With Indicator and Check Button

With Indicator and Check Button





Coil Voltage Code

(Standard Stock Items in Bold)

AC6V, AC12V, AC24V, AC110V, AC120V,

DC6V, DC12V, DC24V, DC48V, DC110V

AC240V,

# Signaling Lights


*Blade type not TUV tested or CE marked.
Side flange model mounts directly to page

Side flange model mounts directly to panel with no socket required.

Ordering Information					
When ordering, specif	When ordering, specify the Part No. and coil voltage code:				
(example) <b>F</b>	R3B-U	AC120V			
-	Part No.	Coil Voltage Code			

#### Sockets

Relays	Standard DIN Rail Mount	Finger-safe DIN Rail Mount	Through Panel Mount
RR2P	SR2P-05 SR2P-06	SR2P-05C	SR2P-51
RR3PA	SR3P-05 SR3P-06	SR3P-05C	SR3P-51
RR1BA RR2BA RR3B	SR3B-05	_	SR3B-51
		C.	





mounted using DIN rail BNDN1000.

#### Hold Down Springs & Clips

	Appearance	Description	Relay	For DIN Mount Socket	For Through Panel & PCB Mount Socket	
	$\langle \rangle$		RR2P	SR2B-02F1	SR3P-01F1	
		Pullover Wire Spring	RR3PA	SR3B-02F1	3036-0161	
			RR1BA, RR2BA, RR3B	SR3B-02F1	SR3B-02F1	
	S	Leaf Spring (side latch)	RR2P, RR3PA	SFA-203	-	

#### Accessories

ltem	Appearance	Use with	Part No.	Remarks
Aluminum DIN Rail (1 meter length)		All DIN rail sockets	BNDN1000	The BNDN1000 is designed to accommodate DIN mount sockets. Made of durable extruded aluminum, the BNDN1000 measures 0.413 (10.5mm) in height and 1.37 (35mm) in width (DIN standard). Standard length is 39" (1,000mm).
DIN Rail End Stop	P	DIN rail	BNL5	9.1 mm wide.
Replacement	1	Horseshoe clip for sockets SR3B-05, SR2P-06, SR3P-06	Y778-011	For use on DIN rail mount socket when using pullover wire hold down
 Hold-Down Spring Anchor	ĝ.	Chair clip for sockets SR2P-05(C), SR3P-05(C)	Y703-102	spring. 2 pieces included with each socket.

Signaling Lights

Relays & Sockets

Timers

Contactors

Terminal Blocks

**Circuit Breakers** 

#### Specifications

Contact Material		Silver				
Contact Resistance 1		30 mΩ maximum				
Minimum Applica	able Load	1V DC, 10 mA				
Operating Time	2	25 ms maximum				
Release Time	2	25 ms maximum				
Power Consump	tion (approx.)	AC: 3 VA (50 Hz), 2.5 V DC: 1.5W	/A (60 Hz)			
Insulation Resist	ance	100 MΩ minimum (500	OV DC megger)			
		Between live and dea	d parts:	1500V AC, 1 minute		
	Pin Terminal	Between contact and	coil:	1500V AC, 1 minute		
	Pin terminal	Between contacts of c	lifferent poles:	1500V AC, 1 minute		
Dielectric		Between contacts of t	he same pole:	1000V AC, 1 minute		
Strength	gth Blade Terminal	Between live and dea	d parts:	2000V AC, 1 minute		ed using 5V DC, 1A voltage drop meth
		Between contact and	coil:	2000V AC, 1 minute	Z. Measure bouncing	ed at the rated voltage (at 20°C), excl g
		Between contacts of c	lifferent poles:	2000V AC, 1 minute		under different temperature condition ous Load Current vs. Operating Tempe
		Between contacts of t	he same pole:	1000V AC, 1 minute	Continuo	the code current vs. operating rempt
		Electrical:	1800 operations	/h maximum		
perating Freque	ency	Mechanical:	18,000 operatior	ns/h maximum		
libration Pagista	200	Damage limits:	10 to 55 Hz, amp	olitude 0.5 mm		
Vibration Resistance		Operating extremes:	10 to 55 Hz, amp	olitude 0.5 mm		
Shock Resistanc	0	Damage limits:	1000 m/s² (100g	)		
Shock hesistance		Operating extremes:	100 m/s² (10G)			
Mechanical Life		10,000,000 operations	\$			
Electrical Life		200,000 operations (22	20V AC, 5A)			
Operating Tempe	erature <sup>3</sup>	-25 to +40°C (no freez	zing)			
Operating Humid	ity	5 to 85% RH (no cond	ensation)			
Weight (approx.)	(Standard type)	RR2P: 90g, RR3PA: 96	g, RR1BA/RR2BA/R	IR3B: 82g		

#### **Coil Ratings**

		Rated Current (m	A) ±15% (at 20°C)	Coil Resistance (Ω)	Operati	ng Characteristics (values	at 20°C)			
Rated Vo	oltage (V)	50 Hz	60 Hz	±10% (at 20°C)	Maximum Continuous Applied Voltage	Pickup Voltage	Dropout Voltage	Con		
	6	490	420	4.9				Contactors		
	12	245	210	18				ors		
AC	24	121	105	79	110%	110% 80% maximum 30	1100/	90% movimum	30% minimum	
(50/60 Hz)	110	27	23	1,680			30 % IIIIIIIIIIIIII			
	120	24	20.5	2,100						
	240	12.1	10.5	8,330					_	
	6	240		25				Terminal		
	12	120		100				inal		
DC	24	6	0	400	400 110%	80% maximum	10% minimum	Blocks		
	48	3	0	1,600				ks		
	110	1	3	8,460						

#### **Contact Ratings**

TÜV Ratings Voltage 240V AC

30V DC

Maximum Contact Capacity							
Continuous	Allowable Co	ontact Power	Rated Load				
Current	Resistive Load	Inductive Load	Voltage (V)	Res. Load	Ind. Load		
	1650VA AC 300W DC		110 AC	10A	7.5A		
10A			220 AC	7.5A	5A		
	00011 20		30 DC	10A	5A		
Note: Inductive load for the rated load — $\cos \varphi = 0.3$ , L/R = 7 ms							

AC: cos ø = 1.0, DC: L/R = 0 ms

#### **UL Ratings**

1	o = natingo						
	Voltage	Resistive	General use	Horse Power Rating			
	240V AC	10A	7A	1/3 HP			
	120V AC	10A	7.5A	1/4 HP			
	30V DC	10A	7A	_			

#### **CSA Ratings**

Voltage	Resistive	General use
240V AC	10A	7A
120V AC	10A	7.5A
100V DC	_	0.5A
30V DC	10A	7.5A

#### **Socket Specifications**

10A

10A

	Relays	Terminal	Electrical Rating	Wire Size	Torque
	SR2P-05	M3 screw with captive wire clamp	300V, 10A	Maximum 2 - #12 AWG	9 - 11.5in•lbs
	SR2P-05C	M3 screw with captive wire clamp, fingersafe	300V, 10A	Maximum 2 - #12 AWG	9 - 11.5in•lbs
	SR2P-06	M3 screw with captive wire clamp	300V, 10A	Maximum 2 - #12 AWG	9 - 11.5in•lbs
DIN Rail Sockets	SR3P-05	M3 screw with captive wire clamp	300V, 10A	Maximum 2 - #12 AWG	9 - 11.5in • lbs
OURCES	SR3P-05C	M3 screw with captive wire clamp, fingersafe	300V, 10A	Maximum 2 - #12 AWG	9 - 11.5in•lbs
	SR3P-06	M3 screw with captive wire clamp	300V, 10A	Maximum 2 - #12 AWG	9 - 11.5in•lbs
	SR3B-05	M3 screw with captive wire clamp	300V, 15A (10A)* (*CSA rating)	Maximum 2 - #12 AWG	9 - 11.5in • lbs
Through	SR2P-51	Solder	300V, 10A	—	—
Panel Mount	SR3P-51	Solder	300V, 10A	—	—
Sockets	SR3B-51	Solder	300V, 10A	—	—

786



Switches & Pilot Lights

Signaling Lights


Relays & Sockets

Timers


#### **Characteristics (Reference Data)**


#### **Electrical Life Curves**






#### **Maximum Switching Capacity**







#### Continuous Load Current vs. Operating Temperature Curve (Standard Type, With Check Button, and Side Flange Type)



#### Internal Connection (View from Bottom) Standard Type



#### With Indicator (-UL type)



787

#### **Dimensions (mm)**

#### RR3PA-U/RR3PA-UL

Total length from panel surface including relay socket SR3P-05: 84.5 (87.5) max., SR3P-511: 63 (68) max.


55.5 m

9.9

.13


3.0 ¥ ø2.0 oblong hole


Ξ



#### RR1BA-U/RR2BA-UL/RR2BA-U RR2BA-UL/RR3B-U/RR3B-UL

RR2P-U/RR2P-UL





# RR1BA-US/RR2BA-US/RR3B-US Ъ

47.5 m


73.5



4

spring

Dimensions in the () include a hold-down s



16.




#### **Standard DIN Rail Mount Sockets**


47.5 max

SR2P-05

SR3P-05



SR3P-06




**Circuit Breakers** 




Contactors

#### **Standard DIN Rail Mount Sockets**



#### **Finger-safe DIN Rail Mount Sockets** SR2P-05C




#### **Through Panel Mount Socket** SR2P-51

7.5

SR3B-51

0 0 0 →||3.5 - 35 - →



11 max.

6.5

Terminal Arrangement


123

(Bottom View)

6.75


1.5 min.

When two or more sockets are mounted side by side: L = 38 (N - 1) + 35.5N: No. of sockets mounted



2-ø4.2 Mounting Holes (M4 Tapped Holes)

(Tolerance 0.3)



11





Timers



Switches & Pilot Lights

Signaling Lights

**Relays & Sockets** 

SR3P-05C

SR3P-51


10 8 (Bottom View)

### **Operating Instructions**

#### **Driving Circuit for Relays**


- 1. To ensure correct relay operation, apply rated voltage to the relay coil.
- 2. Input voltage for the DC coil:

A complete DC voltage is best for the coil power to make sure of stable relay operation. When using a power supply containing a ripple voltage, suppress the ripple factor within 5%. When power is supplied through a rectification circuit, the relay operating characteristics, such as pickup voltage and dropout voltage, depend on the ripple factor. Connect a smoothing capacitor for better operating characteristics as shown below.




#### 3. Leakage current while relay is off:

When driving an element at the same time as the relay operation, special consideration is needed for the circuit design. As shown in the incorrect circuit below, leakage current (lo) flows through the relay coil while the relay is off. Leakage current causes coil release failure or adversely affects the vibration resistance and shock resistance. Design a circuit as shown in the correct example.



4. Surge suppression for transistor driving circuits:

When the relay coil is turned off, a high-voltage pulse is generated, causing a transistor to deteriorate and sometimes to break. Be sure to connect a diode to suppress the back electromotive force. Then, the coil release time becomes slightly longer. To shorten the coil release time, connect a Zener diode between the collector and emitter of the transistor. Select a Zener diode with a Zener voltage slightly higher than the power voltage.




#### **Protection for Relay Contacts**

 The contact ratings show maximum values. Make sure that these values are not exceeded. When an inrush current flows through the load, the contact may become welded. If this is the case, connect a contact protection circuit, such as a current limiting resistor.

#### 2. Contact protection circuit:

When switching an inductive load, arcing causes carbides to form on the contacts, resulting in increased contact resistance. In consideration of contact reliability, contact life, and noise suppression, use of a surge absorbing circuit is recommended. Note that the release time of the load becomes slightly longer. Check the operation using the actual load. Incorrect use of a contact protection circuit will adversely affect switching characteristics. Four typical examples of contact protection circuits are shown in the following table:



3. Do not use a contact protection circuit as shown below:

	This prot opening contacts is discha contact v
C Load	This prot opening

This protection circuit is very effective in arc suppression when opening the contacts. But, the capacitor is charged while the contacts are opened. When the contacts are closed, the capacitor is discharged through the contacts, increasing the possibility of contact welding.

This protection circuit is very effective in arc suppression when opening the contacts. But, when the contacts are closed, a current flows to charge the capacitor, causing contact welding.

Generally, switching a DC inductive load is more difficult than switching a DC resistive load. Using an appropriate arc suppressor, however, will improve the switching characteristics of a DC inductive load.

#### Soldering

- 1. When soldering the relay terminals, use a soldering iron of 30 to 60W, and quickly complete soldering (within approximately 3 seconds).
- 2. Use a non-corrosive rosin flux.

#### **Operating Instructions con't**

# Switches & Pilot Lights

**Relays & Sockets** 

# Other Precautions 1. General notice:

To maintain the initial characteristics, do not drop or shock the relay.

The relay cover cannot be removed from the base during normal operation. To maintain the initial characteristics, do not remove the relay cover.

Use the relay in environments free from condensation, dust, sulfur dioxide (SO<sub>2</sub>), and hydrogen sulfide (H<sub>2</sub>S).

Make sure that the coil voltage does not exceed applicable coil voltage range.

- 2. UL and CSA ratings may differ from product rated values determined by IDEC.
- 3. Do not use relays in the vicinity of strong magnetic field, as this may affect relay operation.

#### Safety Precautions

- Turn off the power to the relay before starting installation, removal, wiring, maintenance, and inspection of the relays. Failure to turn power off may cause electrical shock or fire hazard.
- Observe specifications and rated values, otherwise electrical shock or fire hazard may be caused.
- Use wires of the proper size to meet voltage and current requirements. Tighten the terminal screws on the relay socket to the proper tightening torque.
- Surge absorbing elements on AC relays with RC or DC relays with diode are
  provided to absorb the back electromotive force generated by the coil. When
  the relay is subject to an excessive external surge voltage, the surge absorbing element may be damaged. Add another surge absorbing provision to the
  relay to prevent damage.

#### Precautions for the RU Relays

- Before operating the latching lever of the RU relay, turn off the power to the RU relay. After checking the circuit, return the latching lever to the original position.
- Do not use the latching lever as a switch. The durability of the latching lever is a minimum of 100 operations.
- When using DC loads on 4PDT relays, apply a positive voltage to terminals of neighboring poles and a negative voltage to the other terminals of neighboring poles to prevent the possibility of short circuits.
- DC relays with a diode have a polarity in the coil terminals. Apply the DC voltage to the correct terminals.



