









## **Model Number**

#### UB400-F77-E0-V31


Ultrasonic direct detection sensor

#### **Features**

- Miniature design
- Program input
- · Degree of protection IP67
- Switching status indicator, yellow LED

## **Diagrams**

## Characteristic response curve





## **Technical data**

aenerai specifications	
Sensing range	25 400 mm
Adjustment range	40 400 mm
Unusable area	0 25 mm
Standard target plate	20 mm x 20 mm
Transducer frequency	approx. 300 kHz

Nominal ratings
Time delay before availability t<sub>v</sub>

Limit data

Limit data

Permissible cable length max. 300 m

Indicators/operating means LED yellow

Electrical specifications
Rated operating voltage U<sub>e</sub> 24 V DC

Operating voltage  $U_B$  20 ... 30 V DC , ripple 10  $\%_{SS}$ ; 12 ... 20 V DC sensitivity

≤ 150 ms

reduced to 90 %

switching state and flashing: Teach-In

No-load supply current  $I_0 \le 20 \text{ mA}$ 

Input

Input type 1 program input

Level low level : 0 ... 0.7 V (Teach-In active) high level : U<sub>B</sub> or open input (Teach-In inactive)

 $\begin{array}{ll} \text{Input impedance} & 16 \text{ k}\Omega \\ \text{Pulse length} & \geq 3 \text{ s} \end{array}$ 

Output

Output type 1 switch output E0, NPN, NO

Rated operating current I<sub>e</sub> 200 mA , short-circuit/overload protected

 $\begin{array}{lll} \mbox{Voltage drop } \mbox{U}_d & \leq 2 \ \mbox{V} \\ \mbox{Switch-on delay } \mbox{t}_{on} & \leq 75 \ \mbox{ms} \\ \mbox{Repeat accuracy} & \pm 1 \ \mbox{mm} \\ \mbox{Switching frequency f} & 5 \ \mbox{Hz} \\ \mbox{Range hysteresis H} & \mbox{typ. 4 mm} \\ \mbox{Off-state current } \mbox{I}_r & \leq 0.01 \ \mbox{mA} \\ \mbox{Temperature influence} & + 0.17 \ \%/K \\ \end{array}$ 

Ambient conditions

 Ambient temperature
 -25 ... 70 °C (-13 ... 158 °F)

 Storage temperature
 -40 ... 85 °C (-40 ... 185 °F)

 Shock resistance
 30 g . 11 ms period

Shock resistance 30 g , 11 ms period Vibration resistance 10 ... 55 Hz , Amplitude  $\pm$  1 mm

Mechanical specifications

Connection type M8 x 1 connector , 4-pin

Degree of protection IP67

Material
Housing Polycarbonate

Transducer epoxy resin/hollow glass sphere mixture; polyurethane foam

Installation position any position

Mass 10 g

Tightening torque, fastening screws max. 0.2 Nm

Compliance with standards and

directives
Standard conformity

Standards EN 60947-5-2:2007

IEC 60947-5-2:2007


Approvals and certificates

UL approval cULus Listed, General Purpose
CSA approval cCSAus Listed, General Purpose


CCC approval / marking not required for products rated

<36

## **Dimensions**



# **Electrical Connection**



# **Pinout**



Wire colors in accordance with EN 60947-5-2

1	BN	(brown
2	WH	(white)
3	BU	(blue)
4	BK	(black)

### **Accessories**

#### **UB-PROG4-V31**

Programming unit for ultrasonic sensors with Teach-in input at pin 2

#### **OMH-ML7-01**

Mounting bracket

#### V31-GM-2M-PVC

Female cordset, M8, 4-pin, PVC cable

#### V31-WM-2M-PVC

Female cordset, M8, 4-pin, PVC cable

#### **Description of Sensor Function**

The ultrasonic sensor transmits ultrasonic packets in quick succession and responds to their reflection off the detected object. The sensor has a switch output. The switching point is progammable (Teach-In). Objects beyond the taught-in switching point are not detected (background

## **Teach-In of Switching Point SP**

To teach in a switching point, proceed as follows:

- 1. Connect the sensor and turn on the operating voltage.
- 2. Place the object to be detected at the required distance.
- Connect the teach-in input (ET) to -U<sub>B</sub>. This can be done usingthepushbutton or the controller.
   The LED will start flashing after 3 seconds to indicate that the sensor is ready to start the teach-in process (\*).
   Disconnect the teach-in input (ET) with -U<sub>B</sub>. The switching point SP has now been taught in (\*).
- If no object is detected within the sensing range of the sensor, the sensor will start flashing at a faster rate. The switching point remains (\*) unchanged.

## Switching characteristics and display LED

unusable	Sensing range	Output	LED
area	Adjustment range		
	•	-U <sub>B</sub>	Off
	•	+U <sub>B</sub>	On
		Unde	efined

= Object position

#### Mounting instruction

If the sensor is operated at temperatures below 0 °C, use the supplied distance plate. Only use the two rearmost mounting holes (located opposite to the transducer) for mounting the sensor.

# **Safety Note**



The use of this device in applications, where the safety of persons depends from the devices function, is not allowed!