







Model number


VAA-4E-G2-ZA

G2 flat module 4 inputs (PNP)


Features

- AS-Interface certificate
- Protection degree IP67
- Addressing jack
- Flat cable connection with cable piercing technique, variable flat cable guide
- Inputs for 2- and 3-wire sensors
- Power supply of inputs from the module
- · Function display for bus and inputs
- Monitoring of sensor overloads


Dimensions



Electrical connection



Indicating / Operating means



| Ta alamia al stata | | | |
|---|----------------|---|---|
| Technical data | | | |
| General specifications | | | |
| Slave type | | Standard slave | |
| AS-Interface specification | | V3.0 | |
| Required master specification | | ≥ V2.0 | |
| UL File Number | | E87056 | |
| ndicators/operating means | | | |
| LED FAULT | | error display; LED red red: communication error or red flashing: overload of sen | |
| LED PWR | | AS-Interface voltage; LED gr | |
| LED IN | | switching state (input); 4 LEI | O yellow |
| Electrical specifications | | | |
| Rated operating voltage | U _e | 26.5 31.6 V from AS-Inter | face |
| Rated operating current | l _e | \leq 40 mA (without sensors) / | max. 240 mA |
| Protection class | | III | |
| nput | | | |
| Number/Type | | 4 inputs for 2- or 3-wire sens | ors (PNP), DC |
| Supply | | from AS-Interface | |
| Voltage | | 21 31 V | |
| Current loading capacity | | \leq 200 mA ($T_B \leq$ 40 °C), \leq 150 mA ($T_B \leq$ 60 °C), short-circuit protected | |
| Input current | | ≤ 8 mA (limited internally) | |
| Switching point | | < 4.5 ··· A | |
| 0 (unattenuated) | | ≤ 1.5 mA | |
| 1 (attenuated) | | ≥ 4.5 mA | |
| Signal delay | | < 2 ms (input/AS-Interface) < 250 Hz | |
| Signal frequency | | ≥ 200 HZ | |
| Programming instructions | | 0.04 | |
| Profile | | S-0.1 | |
| IO code ID code | | 1 | |
| ID1 code | | F | |
| ID2 code | | F | |
| Data bits (function via AS-Interfa | ce) | input | output |
| D0 | 00) | IN1 | - |
| D1 | | IN2 | |
| D2 | | IN3 | |
| D3 | | IN4 | - |
| Parameter bits (programmable v | ria AS-i) | function | |
| P0 | | munication fails | outputs maintain the status if co f communication fails, the outp ng) |
| P1 | | Input filter P1 = 0 input filter on, pulse s P1 = 1 input filter off (basic s | |
| P2 | | Synchronous mode P2 = 0 synchronous mode o | |
| DO. | | P2 = 1 synchronous mode o | ii (basic setting) |
| P3 | | not used | |
| Ambient conditions | | OF 60.80 / 40 440.55 | |
| Ambient temperature | | -25 60 °C (-13 140 °F) | |
| Storage temperature | | -25 85 °C (-13 185 °F) | |
| Mechanical specifications | | ID07 | |
| Protection degree | | IP67 | |
| Connection | | cable piercing method | |
| Connocion | | flat cable yellow inputs: M12 round connecto | r |
| Material | | | r |
| | | | r |
| Material | | inputs: M12 round connecto | r |
| Material Housing | | inputs: M12 round connecto PBT | r |
| Material Housing Mass Mounting Compliance with standards and | directi- | inputs: M12 round connecto PBT 100 g Mounting base | r |
| Material Housing Mass Mounting Compliance with standards and wes Directive conformity | directi- | inputs: M12 round connecto PBT 100 g Mounting base | r |
| Material Housing Mass Mounting Compliance with standards and ves Directive conformity EMC Directive 2004/108/EC | directi- | inputs: M12 round connecto PBT 100 g Mounting base | |
| Material Housing Mass Mounting Compliance with standards and ves Directive conformity EMC Directive 2004/108/EC Standard conformity | directi- | inputs: M12 round connecto PBT 100 g Mounting base EN 61000-6-2:2001, EN 610 | |
| Material Housing Mass Mounting Compliance with standards and ves Directive conformity EMC Directive 2004/108/EC Standard conformity Noise immunity | directi- | inputs: M12 round connecto PBT 100 g Mounting base EN 61000-6-2:2001, EN 6100 EN 61000-6-2:2001 | |
| Material Housing Mass Mounting Compliance with standards and ves Directive conformity EMC Directive 2004/108/EC Standard conformity Noise immunity Emitted interference | directi- | inputs: M12 round connecto PBT 100 g Mounting base EN 61000-6-2:2001, EN 6100 EN 61000-6-2:2001 EN 61000-6-4:2001 | |
| Material Housing Mass Mounting Compliance with standards and ves Directive conformity EMC Directive 2004/108/EC Standard conformity Noise immunity Emitted interference Input | directi- | inputs: M12 round connecto PBT 100 g Mounting base EN 61000-6-2:2001, EN 6100 EN 61000-6-2:2001 EN 61000-6-4:2001 EN 61131-2:2007 | r 000-6-4:2001, EN 50295:1999 |
| Material Housing Mass Mounting Compliance with standards and ves Directive conformity EMC Directive 2004/108/EC Standard conformity Noise immunity Emitted interference Input Protection degree | directi- | inputs: M12 round connecto PBT 100 g Mounting base EN 61000-6-2:2001, EN 6100 EN 61000-6-2:2001 EN 61000-6-4:2001 EN 61131-2:2007 EN 60529:2000 | 000-6-4:2001, EN 50295:1999 |
| Material Housing Mass Mounting Compliance with standards and res Directive conformity EMC Directive 2004/108/EC Standard conformity Noise immunity Emitted interference Input | directi- | inputs: M12 round connecto PBT 100 g Mounting base EN 61000-6-2:2001, EN 6100 EN 61000-6-2:2001 EN 61000-6-4:2001 EN 61131-2:2007 | 000-6-4:2001, EN 50295:1999 |

Function

The VAA-4E-G2-ZA is an AS-Interface coupling module with 4 inputs. Mechanical contacts (e.g. push buttons) and 2- and 3-wire sensors can be connected to the inputs.

The IP67 flat module features an integrated addressing jack and is ideal for applications in the field.

Sensors are connected via M12 x 1 quick disconnects. The current switching state of each channel is indicated by an LED. An additional LED monitors the AS-Interface communication and indicates when the module has an address of zero.

The input is monitored for short circuits. In a failure case, the module disconnects from the AS-Interface and an error is indicated.

The U-G3FF mounting base is used as a standard connection to the AS-Interface. The flat cables can be installed in two orientation within the base. This means, for example, that 90° curves can be laid with very tight radii (variable flat cable guide). If input and output modules are used in an application, the flat cable for the external power supply can be placed in the base of the module, since the module does not access this line. The advantage is that both flat cables can be placed in parallel without destroying the module due to a wrong connection.

The mounting base for the module is sold separately.

Accessories

VBP-HH1-V3.0

AS-Interface Handheld

VAZ-PK-1,5M-V1-G

Adapter cable module/hand-held programming device

VAZ-FK-ED-G2

AS-Interface end seal for G2 modules

Matching system components

U-G3FF

AS-Interface module mounting base for connection to flat cable (AS-Interface and external auxiliary power)

PEPPERL+FUCHS



Notes

Do not connect inputs and outputs, which are supplied via the module from AS-interface or via auxiliary power, with power supply and signal circuits with external potentials.